User Manual



E1050TW

Digital Camera



Preparations

Basic operation

Camera function controls

Playback

Using the Menus

Camera connectivity

Appendix

Warning

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

For customers in the U.S.A.

Tested To Comply With FCC Standards FOR HOME OR OFFICE USE

FCC Statement

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For customers in Europe

CE" mark indicates that this product complies with the European requirements for safety, health, environment and customer protection. "CE" mark cameras are intended for sales in Europe.

This symbol [crossed-out wheeled bin WEEE Annex IV] indicates separate collection of waste electrical and electronic equipment in the EU countries. Please do not throw the equipment into the domestic refuse. Please use the return and collection systems available in your country for the disposal of this

Declaration of Conformity

Model Name : F1050TW

Trade Name : GE

product.

Responsible Party: General Imaging Co. Address : 2158 W. 190th Street.

Torrance, CA 90504, USA

Telephone Number: 1-800-730-6597

Conforms to the following Standards:

EMC: EN 55022:1998/A1:2000/A2:2003 Class B

EN 55024:1998/A1:2001/A2:2003

EN 61000-3-2:2000/A1:2001 EN 61000-3-3:1995/A1:2001

following the provision of the EMC Directive

(89/336/EEC,2004/108/EEC)

Safety precautions

Camera notes:

- Do not store or use the camera in the following types of locations:
 - In the rain or very humid and dusty places.
 - In a place where the camera can be exposed directly to the sunlight or subject to high temperature, e.g., inside a closed car in summer.
 - In a place where the camera is subject to a high magnetic field, e.g., near motors, transformers or magnets.
- Do not place the camera on a wet surface or places where dripping water or sand may come in contact with the camera, which may cause irrepairable faults.
- If the camera will not be used for a long period of time, we suggest you remove the battery and the memory card.
- If the camera is moved suddenly from a cold location to a warm place, moisture may condense inside the camera. We suggest you wait for a while before turning on the camera.
- No compensation for loss of recordings. Loss of recordings cannot be compensated for if a malfunction of your camera or recording media, etc, makes the playback of recordings not possible.

Battery notes:

- Incorrect use of the batteries may cause them to leak, become hot, ignite or burst. Always observe the precautions given below.
 - Do not expose the batteries to water, and take particular care to keep the terminals dry.
 - Do not heat the batteries or throw them into a fire.
 - Do not attempt to deform, disassemble or modify the batteries.
 - Use only the GE charger included in the package to charge the lithium battery.
- Keep the batteries out of reach of babies and small children.
- In cold locations, battery performance deteriorates and the time for which they can be used shortens markedly.

Memory card notes:

- When using a new memory card, or a memory card has been initialized by a PC, be sure to format the card with your digital camera before using it.
- To edit image data, copy the image data to the PC's hard disk and then format the memory card if upgrading the firmware.
- Do not change or delete the directory names, or file names in the memory card from your PC, as this may make it impossible to use the card in your camera.

Before you start

Preface

Thank you for purchasing this GE digital camera. Please read this manual carefully and keep it in a safe place for future reference.

Copyright

© Copyright 2008 General Imaging Company. All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form, by any means, without the prior written permission of General Imaging Company.

Trademarks

All trademarks mentioned in this manual are used for identification purposes only and are properties of their respective owners.

Safety information

Please read the following important information carefully before using the product.

- Do not take apart or attempt to service the camera yourself.
- Do not drop or knock the camera. Improper handling may damage the product.
- Turn off the camera before inserting or removing the battery and memory card.
- Use only the type of battery and charger that came with your camera. Using other types of batteries or chargers may damage the camera and invalidate the warranty.
- When using Li-ion batteries in this product, ensure that they are inserted correctly. Inserting the batteries upside down can cause damage to the camera and possibly start a fire.
- Do not touch the camera lens.
- Do not expose the camera to moisture, or extreme temperatures. Extreme environments may shorten the life of your camera or damage the batteries.

- Do not use or store the camera in dusty, dirty, or sandy areas, as its components may be damaged.
- Do not expose the lens to direct sunlight for extended periods.
- Download all pictures and remove the batteries from the camera if you are going to store the camera for long periods.
- Do not use abrasive cleansers, alcohol-based, or solvent-based cleaners to clean the camera. Wipe the camera with a slightly damp soft cloth.

About this manual

This manual provides you with instructions on how to use your GE digital camera. Every effort has been made to ensure that the contents of this manual are accurate, but General Imaging Company reserves the right to make changes without notice.

Symbols used in this manual

Throughout this manual, the following symbols are used to help you locate information quickly and easily.



Indicates the useful information to know.



Indicates the precautions to be taken while operating the camera.

About the LCD screen

The LCD touch-screen (touch panel) can be used to operate the camera.

When you turn the camera on, various icons are shown on the LCD screen to indicate the current camera settings and status. To learn more about the displayed icons, see **LCD Screen Display** on page 18.

LCD Screen notes:

Extremely high-precision technology has been used to manufacture the LCD screen so that most of the pixels are operational for use. However, there may be some minute points (black, white, red, blue or green) that constantly appear on the LCD screen. These points are normal in the manufacturing process and the recording is not affected in any way.

- If the LCD monitor is damaged, take particular care with the liquid crystal in the monitor. If any of the following situations arise, take the urgent action indicated.
- If liquid crystal comes in contact with your skin, wipe the area with a cloth and then wash thoroughly with soap and running water.
- If liquid crystal gets into your eye, flush the affected eye with clean water for at least 15 minutes and then seek medical assistance.
- If liquid crystal is swallowed, flush your mouth thoroughly with water. Drink large quantities of water and induce vomiting. Seek medical assistance.

Contents

Warning	
Safety precautions	ii
Before you start	1
Preface	1
Copyright	1
Trademarks	1
Safety information	1
About this manual	
Symbols used in this manual	2
About the LCD screen	3
Cambanda	4
Contents	
Getting ready	8
Getting ready	8
Getting ready Unpacking	8 9
Getting ready Unpacking Identifying the components	8 9 11
Getting ready Unpacking Identifying the components Charging the battery	
Getting ready Unpacking Identifying the components Charging the battery Inserting the battery	

Camera function controls29
Shooting in Auto mode29
Using the zoom function29
Picture size and quality30
Picture size setup30
Picture quality setup30
31 Flash mode
Macro mode32
[空] Face detection33
Self-portrait and continuous34
EV exposure compensation35
🚇 WB (White Balance)36
ISO37
🟂 Color effect38
Scene mode39
🔀 Sport40
100 Indoor40
8 Snow 40

Fireworks	40
museum	40
Night landscape	40
🔤 Children and animals	40
🌃 Trees and leaves	40
Sunset	40
Glass layer	40
Landscape	40
🗐 Night portrait	40
🥦 Portrait	40
🔀 Panorama mode	41
Image Stabilization mode	
Playback mode	44
Picture preview	
Play the slides	45
Rotate the pictures	45
Red-eye removal	46
Sound recording/playing	

Resize the picture47	Protected	57
Picture cropping48	Delete	58
Text display49	DPOF (Digital Print Order Format)	60
Operational menus50	Slides	60
Photographing setting50	Camera setting menu	61
AF mode51	Format memory	61
AF-assist beam51	Beep	62
Exposure metering52	LCD brightness	
Continuous shot52	Power saver	63
Quick review53	Date / Time	64
Digital zoom54	Zone	64
Date printed54	File numbering	65
B Shutter (Slow Shutter)55	Language	65
Blink detection55	Video system	66
Video recording setup56	Copy to Card	66
Expo metering setup56	Reset settings	67
Playback menu setup57	FW version	67


Ju	mera connection6	8
	Connecting to a TV6	8
	Connect Your Camera to a HDMI TV	
	to View Videos6	9
	Connecting to the PC7	1
	Setting the USB mode7	1
	Transferring files to your PC7	1
	Connecting to a PictBridge compatible	
	printer	4
	printer	
	•	4
	Setting the USB mode7	'4 '5
	Setting the USB mode7 Connecting the camera and printer7	'4 '5 '6
	Setting the USB mode7 Connecting the camera and printer 7 Using the PictBridge menu7	4 5 6
	Setting the USB mode	74 75 76 76 77
	Setting the USB mode	'4 '5 '6 '7

Appendices	79
Specifications: E1050TW	79
Error messages	83
Troubleshooting	85


Getting ready

Unpacking

Your package should contain the camera model you purchased along with the following items. If anything is missing or appears to be damaged, please contact your vendor.





Identifying the components




Top View

Bottom View





Left View



1	Flash	10	Playback button
2	Mic	11	Shutter button
3	AF assist beam/Timer indicator	12	Zoom scroll wheel
4	Lens	13	Speaker
5	LCD screen	14	Tripod mount point
6	Wrist strap mount	15	HDMI port
7	Power indicator	16	Memory card/Battery compartment
8	Power button	17	USB/ AV port
9	Status LED		

Charging the battery

- 1. Place the battery into the charger as shown.
- 2. Plug one end of the connecting cable into the charger base.
- Plug the other end of the connecting cable into a wall outlet.




Leave the battery to charge until the charger light goes green.

(To maximize battery life, the first charge should be at least 4 hours)



The charger is for indoor use only.




Inserting the battery

1. Open the battery compartment.






Insert the battery while observing the correct polarity. Use the side of battery to press down the stopper as shown, allowing the battery to be inserted properly.



3. Gently close the battery compartment. Slide the door to the right in lock position.






Battery capacity decreases with usage.

Inserting an optional SD/SDHC card


1. Open the battery compartment.






Optional SD/SDHC cards are not included.
The use of 64MB to 4GB memory cards from recognized manufacturers such as SanDisk, Panasonic and Toshiba is recommended for reliable data storage.

2. Insert an optional SD/SDHC card into the memory card slot as shown.



3. Close the battery compartment.




To remove the SD/SDHC card, open the battery compartment and gently push the card to release it. Pull the card carefully.

Turning on and off

Press the Power button to turn on the camera. To turn off the camera, press the Power button again.

Power button




When the camera is turned on for the first time, it is automatically set to the Auto shooting mode. You can change to other modes in the camera setup. Please see Camera Function Controls on page 29 for more details. The camera will power on in the last shooting mode that it was set to when it was powered off.

Control touch panel

The LCD screen is also a touch panel and has the camera control buttons integrated into it.

Touch panel





About the touch panel buttons:



- Please use your finger to gently touch the camera controls on the touch panel.
- Please do not use any sharp objects to operate the touch panel.
- Please do not use excessive force on the LCD touch panel.

Time and language setup

Before you start using the camera, the language and time must be configured from the Setup menu.

To access the Setup menu:

- 1. Press the power button to turn on the camera.
- Touch the icon to enter the Setup menus, then touch Camera setting button to enter the camera setting menu.
- Press the up/down arrows to scroll through each menu page.

Time setup:

- In the Camera Setting menu, select Date/Time.
- Press the up/down arrows to set the time and date.



3. Once the date and time are set, press the **OK** button to confirm and save.

Language setup:

- Select Language from the camera setup menu page.
- Press up/down arrow key in each page to find your language.





3. Press the button with the language you want to set for the camera, then press the witten to confirm and save.

LCD Screen display

Still Shooting mode display

Mode icon: 💿 🖾 🖂 🕬





- 1 Shooting mode icon
 - Auto mode

- Manual mode
 Seene mode
- Panorama stitching mode
- Stabilization mode
- 2 Memory card / internal memory display
- 3 Number of remaining shots
- 4 Low battery icon
- 5 Zoom indicator
- 6 Battery level indicator
- 7 Setup menu icon
- 8 Macro mode display
 - Macro mode off
 - Macro mode on
- 9 Flash mode display
 - Auto flash
 - Red-eye Reduction flash


- 🚣 Slow Synchro flash
- Red-Eye Reduction + Slow Synchro flash
- ₹ Flash off
- 考 Forced flash
- 10 Screen display DISP icon (please refer to Switch Between Screens on page 22)
- 11 Function Page icon
- 12 EV indicator
- 13 Self-Portrait and Continuous Shot display
- 14 Face Detection and Smile Detection display.
- 15 Picture size and quality display
- 16 Travel time icon
- 17 Continuous Shot display
- 18 B Shutter (slow shutter) icon
- 19 Expo Metering mode
 - (♦) Spot AE
 - [Centered-Weight
 - [∰] AIAE

- 20 Focus mode
 - Single point
 - Rulti point
- 21 Face Detection / Blink Detection icon
- 22 Smile Detection icon
- 23 WB (white balance) display (only available under Manual mode)
- 24 ISO (only available under Manual mode)
- 25 Color effect display (only available under Manual mode)

Movie mode on-screen icons:

Mode icon:





- 1 Shooting mode icon
- 2 Memory card / internal memory display
- 3 Remaining recording time
- 4 Low battery icon
- 5 Zoom indicator
- 6 Battery level indicator
- 7 Setup menu icon
- 8 Macro mode indicator



Macro mode off



Macro mode on

9 Screen display DISP icon (please refer to

Screen Display on page 22)

- 10 FV indicator
- 11 Self-Portrait and Continuous Shot display
- 12 Movie size and quality display
- 13 Travel time icon
- 14 Expo Metering mode
 - 『♦』 Spot AE
 - Centered-Weight
 - [∰] Ai AE
- 15 Recording status icon
 - Recording standby
 - Recording





For best results the use of an SD memory card is recommended when shooting a movie. The camera's built-in memory is limited and may cause stuttering and noise if used for movie recording.



While recording, the optical zoom is fixed but the digital zoom can go up to the maximum 4.5x.

Playback mode on-screen icons:





- 1 Slideshow mode
- 2 Memory card / built-in memory display
- 3 Current picture index / total number
- 4 File name
- 5 Date and time captured
- 6 Setup menu
- 7 Screen display DISP (Please refer to Screen Display section on page 22)
- 8 Next page icon
- 9 Audio playback display
- 10 Red-eye Reduction
- 11 Rotate picture
- 12 Delete image
- 13 DPOF printing
- 14 Picture audio status

- 15 File protection
- 16 Change picture size
- 17 Crop picture
- 18 Picture text display

Screen Display

Touch the display contents on the screen:




1. Shooting mode 💿 🚳 🐠

When in shooting mode, touch the to change between the four on-screen displays:



Open Advanced Functions

Show Histogram



2. Recording mode 🖀

When in shooting mode, touch the to change between the two on-screen displays:



Open Advanced Functions

Hide Icon

3. Scene mode SEES

When in Scene mode, the icon at the bottom right is displayed as the scene selection icon:



For relevant settings about scene selection, refer to **Scene Mode** on page 39.

4. Playback mode

When in playback mode, touch the to change between the two on-screen displays:




Open Advanced Functions

Hide Icon

Basic operation


How to take pictures

1.




Hold the camera firmly.

2.



Use the Zoom Wheel to zoom in or out on the object.

3.




Press the shutter button halfway to focus on the center of the viewing object, then completely depress the shutter button to capture the image.


4. The captured image is shown on the LCD screen.


Focus controls

When you press the shutter button halfway, the camera will automatically focus on the viewing object (Auto Focus). Please note that the shutter button is depressed halfway only.









Tips to preventing blurry images

Inadvertent moving of the camera during image capturing is called "camera shake"; on the other hand, movements by the main object during the image capture is called "object blur".

1. Camera shake



Cause of camera shake: Shaking of the hand or arm while pressing the shutter button will result in a blurry image.

How to reduce blur:

 Use a tripod or place the camera on a flat and stable surface.

2. Object blur



Cause of object blur: Even if the camera is stable during image capture, movements by the main object during the exposure duration will result in blurriness of the object.

How to reduce blur:


- Switch to Sport mode when taking a picture of an object in motion.
- Use higher ISO with faster shutter speeds (only available for Manual mode), and press the shutter button before the object starts to move.

How to playback images

The camera provides a hotkey to quickly playback the images you've captured.

To view captured images and movies on the LCD:


 Press the Playback button to switch the camera to Playback mode. The screen will then show the last taken picture or movie segment.




2. Touch the icon on the screen to view picture(s) or movie(s) stored on the memory card or built-in memory area.



- When a movie has been taken, the converse icon will appear on the bottom center of the touch screen. Press the play button to start playback of the movie.
- 4. Function buttons during movie playback:





1	Previous frame	7	Play
2	Pause	8	Rewind
3	Next frame	9	Fast forward
4	Decrease volume	10	Next
5	Increase volume	11	Previous
6	First frame		

- After 2 seconds of movie playback, all icons and buttons shown on the screen will automatically be hidden. Touch anywhere on the screen to show the icons and buttons again.
- 6. During movie playback, touch the button to adjust the audio volume.

How to delete images

In **Playback mode**, touch any place on the screen to display the main options screen and click the Delete icon in to display the **Delete** menu.



Delete pictures or movies:

- Press the Left or Right arrow to select the picture or movie you want to delete.
- 2. Select one of the delete options and then press OK.
 - № Cancel
 - 🔚 Delete picture and sound files

Delete sound/recording files only



3. Press the Cancel button in the top right corner to return to the playback mode.



The on icon during Playback indicates the picture is currently protected and the buttons in the delete option menu cannot be selected.



For **Protection Setting** on files, please refer to the instructions at page 57.

Camera function controls

Shooting in Auto mode 💿

Auto mode is the easiest mode to use to take pictures. While operating in this mode, the camera automatically optimizes your picture for best results.

To take pictures in Auto mode:

- 1. Press **power** button to turn on the camera.
- Touch the Auto mode () button at the top left corner of the screen to enter the mode selection screen (the default mode at camera bootup is Auto mode).
- Compose your picture on the LCD screen and press the shutter button halfway to focus on the subject.
- 4. When the subject is in focus, the green colored focus frame appears on the center of the LCD screen.
- 5. Press **shutter** button fully to capture the image.

Using the Zoom function 🔤

Your camera is equipped with two types of zoom: optical zoom and digital zoom. Use the **zoom scroll** wheel at the top of the camera to zoom in or out on your subject while taking pictures.





Zoom indication scale (please refer to **digital zoom** on page 54)

When the optical zoom factor reaches its maximum value, it stops momentarily. Press and hold the zoom scroll wheel to the furthest position \mathbf{Q} and the zoom will switch over to digital zoom automatically.

Picture size and quality 📠

Picture size setup

The size setting refers to the image resolution in pixels. A higher image resolution allows you to print that image in larger sizes without degrading the image.

To change picture size:

- 1. Touch the lower left corner of the screen to enter the Setup menu.
- 2. Select the picture size.



- 3. Touch the OK button to confirm.
- 4. Number of remaining shots will be shown on screen.



When in picture quality setup menu, touch the to get back to picture size setup menu.



The larger the number of recorded pixels the better the image quality. The smaller the number of recorded pixels the more pictures you can store on a memory card.

Picture quality setup

Picture quality setup can adjust the compression ratio of images saved. Higher picture quality will produce better results but will also use more storage space.

To set up picture quality:

1. Touch the with button at the lower left corner of the screen to enter the Setup menu.

2. Touch the 🔀 button to select the Picture Quality option.



- 3. Select a setting from the 3 options:
 - Picture quality: Best
 - Fig. Picture quality: Fine
 - NO. Picture quality: Normal
- 4. Touch the OK button to confirm.
- 5. Number of remaining shots will be shown on the screen.

Flash mode 🍕

Touch the Setup button on the screen to enter the Setup menu and switch between 6 flash modes:



• Kanalan Auto flash

The camera will automatically control the flash based on lighting conditions.



Red-eye reduction

The camera will pre-flash to reduce Red-eve.

S Forced flash

The camera will enable flash under all conditions.

Red-eye Reduction + Slow Synchro flash

The camera will use the Slow Synchro flash and Red-eve reduction function.

The camera will disable the flash under all conditions.

• 🛵 Slow Synchro flash

The camera will use background expo metering as basis for accurate foreground and background exposure levels.

Macro mode 🚱

1. In **Macro mode**, you can capture object details at a close distance. Touch the contains icon to enter the Macro mode setup menu:



- 2. Touch the button and button on screen to switch to Macro mode.
- Macro mode off.
- Macro mode on

Use this option to focus on objects within 5cm of the camera lens.

Face detection 😰

Face Detection and Auto Focus can be used in shooting mode to automatically focus on a subject's face and optimize exposure. When Smile Detection is enabled, the camera will automatically take the picture when the subject smiles.

1. In Shooting mode, Touch the button at the bottom right of the screen until the EV face detection con appears.



- 2. Press (2) to select from three options:
 - 💬 Face Detection: Off
 - [2] Face Detection: On

- 😂 Face Detection: Smile Detection.
- 3. Touch OK to confirm.
- 4. When Face Detection is enabled, please hold the camera steady and point at the subject's face for detection. After the camera has detected the subject's face, a box will appear around the face on the screen. Press the shutter button halfway and completely depress after auto focusing to take the picture.
- 5. When Smile Detection is enabled, depress the shutter button halfway to auto focus. Completely depress the shutter. When a smile has been detected, the shutter will automically release until the memory card is filled or any key is pressed.
- For best result, the face of the subject should fill up a larger portion of the LCD screen and be facing the camera as much as possible.

Self-portrait and Continuous shot

To use self portrait timer:

1. In Shooting mode, Touch the button at the bottom right of the screen until the self-portrait button appears.



- 2. Press the button to select from three options:
- Self-portrait off
- 2 second timer

A single picture will be shot 2 seconds after the shutter is pressed.



10 second timer

A single picture will be shot 10 seconds after the shutter is pressed.

- 3. After selecting the **Continuous Shot mode**, the shutter button must be held down to use the function.The Continuous Shooting mode has three options:
- Unlimited shot Press and hold the shutter button for continuous shots until the shutter button is released or the memory is full.
- 3 Continuous shots Take up to 3 continuous shots
- Last 3 continuous shots

Press and hold the shutter button for continuous shots until the shutter button is released, but only the last 3 shots will be saved before the shutter button is released.

EV exposure compensation

Exposure compensation can adjust the exposure value for best picture results. To change the exposure value:

1. In Shooting mode, Touch the button at the bottom right of the screen until the EV Rigidian appears.



- 2. Press the EV icon to enter the exposure compensation setup menu.
- 3. Touch the \Leftrightarrow button to adjust the

picture exposure value range from EV-2.0 to EV+2.0. (each step at 0.3EV)



The text onscreen shows the current value when touching the minus button — to lower the exposure value. Press and hold the button for 2 seconds to automatically lower the value until the meter reaches the minimum.



The text onscreen shows the current value when value. Press and hold the button for 2 seconds to automatically raise the value until the meter reaches the maximum.

WB (White Balance) 🚇

The white balance allows the user to adjust the color temperature under different light sources to ensure accurate color reproduction.

(The WB setting is only available when thecamera is in the

Manual mode).

To set the white balance:

1. In manual shooting mode, touch the button at the bottom right of the screen and then page down. The white balance icon will appear on this page.



- 2. Press the icon to select from 7 modes:
 - 🚇 Auto
 - 🔆 Daylight
 - Cloudy
 - Karr Cold cathode light
 - ## Fluorescent light
 - - Light bulb
 - Custom
- When using the custom white balance, select the button to enter the setup page. Completely depress the shutter button to automatically detect the white balance level and the color of the screen will be matched to the white balance level.
- 4. Press the OK button to confirm the white balance setup.

ISO 🕮

The ISO function allows you to set the camera sensor sensitivity to light. To improve the performance in darker environments, a higher ISO value is required. On the other hand, a lower ISO value is needed when in bright conditions. (The ISO setting is only available when the camera is in the Manual mode).

To set the ISO value:

1. In manual shooting mode, touch the button at the bottom right of the screen and then page down.

The ISO button will appear on this page.



- 2. Press the icon to enter the ISO setup menu.
- Select an ISO level on the screen, Auto, 80, 100, 200, 400, 800, and 1600.
- 4. Touch the OK button to confirm the ISO setting.



Pictures taken with higher ISO levels will contain more noise than lower ISO levels.

Color effect 🔊🗛

The color effect will let you add art effects directly to your pictures. You can try different color combinations to change the mood of the picture.

(The color values can be changed only under ♠M manual mode).

To set up the color effect:

1. In manual shooting mode, touch the button at the bottom right of the screen and then page down. The color effect icon will appear on this page.



- 2. Press the A icon to enter the color effect setup menu with a total of 4 selectable modes:
 - • Auto.
- Sim Black and white
- Sepia
- 🔊 Vivid
- 3. Touch the OK button to confirm the color effect setup.

The screen will reflect the selected color effect. For example, the Sepia color effect is reflected below:



Scene mode SCENE

In **Scene** mode, you can select from a total of 13 scene types to match your needs. Just select the right scene for the occasion and the camera will automatically adjust to the optimal settings.

- 1. Touch the mode button in the upper left corner of the screen. Touch sex button and then press to enter the **Scene mode**.
- 2. The scene mode menu will appear. Choose the appropriate scene mode for your picture and then press ok.



3. Press the sessi mode button at the top left to return to the mode selection screen.





After selecting a mode in the scene mode menu, touch the button to enter the scene description screen.

Sport 🔊



For shooting fast-moving objects, Bring action pictures to life.

Indoor 💹



For indoors shots. Clearly show background and atmosphere.

Snow Programmer



Suitable for snowy landscape. Camera automatically adjusts and corrects exposure value (EV).

Fireworks ***



For shooting at night and fireworks. Shutterspeed is slower than normal. (Use of tripod is recommended).

Museum



For shooting in museums or places where flash is not allowed.

Night landscape W



For shooting night scenes. (Use of tripod is recommended)

Children and animals



For taking pictures of children or animals. The flash will be turned off to not distract the subject.

Trees and leaves



For taking pictures of flowers and plants for more vivid greens.



For shooting sunsets. Vivid reproduction of red and yellow.

Glass layer



For taking pictures of subjects behind a layer of glass or window.

Landscape /



For shooting landscapes. Vivid reproduction of green and blue.

Night portrait (%)



For shooting portraits with night scenes as the background.

Portrait 🖎



For taking pictures of people under normal conditions.

Panorama mode 🖾

Panorama mode allows you to create a panoramic picture. The camera will automatically compose a panoramic picture using the individual shots that you take.

To use Panorama mode:

1. Touch the mode button in the upper left corder, then press **Panorama mode** and or.



Select the order of the shots (default is from right to left) or it will automatically go to the shooting mode after 3 seconds without selection input. 3. Compose your first view on the LCD screen and press the shutter button.



- 4. To capture the second shot, move the camera horizontally until the edges of pictures overlap. Press the shutter button to capture.
- 5. Repeat Step 4 to capture the third and final shot.





- 5. The camera will automatically stitch and save into a panorama picture after the 3rd shot.
- 6. Press the playback button to enter Playback mode and review the panorama result.



- For best results, the use of a tripod is recommended.
- After taking the first picture, the following modes will not be accessible: Flash, Self-timer, Macro and Exposure Compensation.
- When the panorama mode is active, no picture can be deleted during the three shot sequence, and no focus adjustment is allowed.

Image stabilization mode 🐠

The Image Stabilization mode minimizes the effect of hand shake and allows you to take pictures that would otherwise be blurred.



- 1. Touch the **Image Stablization mode** button in the camera menu and then press of to enter.
- 2. Press the shutter halfway to focus on the subject.
- 3. Press the shutter fully to capture the image.



- Use Image Stabilization mode in weak light environments or when in a slow shutter mode to get best results.
- Taking pictures in a strong vibration environment (like shooting in a moving car) may generate a poor picture performance.

Playback mode

Thumbnail view

In **Playback mode**, push the (W) on the zoom wheel once to display thumbnails of pictures and video clips on the LCD screen.

- Use the zoom scroll wheel to switch between the 2x2 or 3x3 thumbnail display.
- 2. Touch the thumbnail image on the screen to view it in full size



When the selected picture is displayed in full size during **Playback Mode**, push the zoom scroll wheel (**W**) toward the right to zoom in on the image.

- Once you have zoomed in, simply touch the up, down, left and right arrow key buttons on screen to change the display position of the zoomed-in image.
- 2. When the image is zoomed in/out, the screen shows the zoomed ratio and the relative proportion to the whole image. See the following demonstration:



 Hold the zoom scroll wheel (W) toward the left to keep zooming out until the size of the image is back to full screen size.




Movie clips cannot be zoomed in.

Slideshow 🕞

In **Playback mode**, touch anywhere on the screen to show the Playback main menu. Press the slide play button to start playing a slideshow.

1. When the slide plays, touch anywhere on the screen to show the operational buttons.



1 Stop

- Play Setup
- 2 Resume



Refer to page 57 for Playback setup.

Picture Orientation 🛅

This function allows you to rotate your pictures.

1. In Playback mode, touch any place on the screen and then the button will appear at the lower right corner of the screen. After this, touch , Picture Rotate button will appear on the screen.



- 2. Press the left/right arrow key to browse the images. Select the desired picture to rotate.
- 3. Set the rotation direction by touching the directional key and press the OK button to confirm (or press the return key to cancel and go back to the main menu of Playback mode).



When the rotation is set, the new image will be saved in the selected format, and the original image will be kept in the memory.

Red-eye removal 💿

The camera provides the Red-eye removal function that allows you to easily remove any red-eye effect in the pictures.

1. In Playback mode, touch any place on the screen and then the High button will appear at the lower right corner of the screen. After this, touch 中間, Red-eve Removal button will appear on the screen.



2. Press the left/right arrow key to browse the images. Select the desired image with the red eye and press the ok button to confirm.



When the function is active, the camera will automatically skip the movie clip and play the next image.

Sound recording/playing 🔑

The Sound Recording/Playing function allows you to record or play sound quickly.

1. In Playback mode, touch anywhere on the screen to see the menu buttons. Touch the \Box , and then touch the sound recording/playing icon button along the bottom.



- 2. Press the left/right arrow key to browse the images. Select the desired image for recording and press the button to confirm.
- 3. The camera will now be in recording mode. It will record audio for 60 seconds and stop automatically, or you can stop it by touching the <u>n</u> button.

4. When the Picture has recorded the sound, touch the button on the screen and enter the sound play menu.



5. Press the OK button to confirm (or press the **return** key to cancel and back to the main menu of Playback mode).



The maximum recording length is 60 seconds.



When the sound is recording or playing, the buttons on the screen are still always active.

Picture resize 🔀

This setting allows you to resize the Picture in a specific resolution and save it as a new image.

1. In Playback mode, touch the bottom right of the screen and then page down. The Resize icon will appear on this page.



- 2. Press the left/right arrow key to browse the images. Select the desired image to resize.
- Select the desired resize value (1024×768 or 640×480) and press the ok button to confirm (or press the return key to cancel and return to the playback main menu).



After resizing the image, the new image will be saved as a new file. The original image will be kept in the memory.



When the original picture size is smaller than **640×480**, the picture can not be resized again.



Rotated pictures cannot be resized.



Panoramic pictures cannot be resized.

Picture cropping 🔀

The picture crop function allows you to crop a desired portion of the image and save it as a new file.

1. In Playback mode, touch the bottom right of the screen and then page down. The cutting icon will appear on this page.



2. Select the desired image and set the cutting region of the image by using zoom scroll wheel and the directional buttons on the screen. Press the ok button to confirm (or press the return key to cancel and return to the playback main menu).

Text display **T**

The text information of the picture includes the bar chart, the IRIS value, the shutter speed, the image resolution, WB (White Balance) value, and the ISO equivalent.

1. In Playback mode, touch the bottom right of the screen and then page down. The text display icon $|\mathbf{T}|$ will appear on this page.



2. Select \mathbf{On} and touch the $\boxed{0}$ % button to complete.



When a movie clip is opened in Playback mode, only the first frame of the clip will be shown but the text will not be shown on the screen.

Operational menus

Photograph setting

Mode icon:

Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode icon:
Mode









In the Photograph mode, touch the button on the screen directly to show the Photograph Configuration.

In any photograph mode, touch the my button to enter set up menu.

Changing settings:

1. Touch the **up/down** arrow keys shown on screen to scroll through setting options.



2. Touch the desired function to show its sub-menu.



3. Change the desired setting(s) and press the OK button to complete (or press the return key to cancel and return to the playback main menu).

AF mode

Use this setting to control the auto-focus mechanism while taking pictures.



There are two options:

- Single AF: A focus frame appears at the center of the LCD screen to focus on the subject.
- Multi AF: The camera automatically focuses the subject in a wide area to find the focus point.

AF assist beam

Use this setting to assist focusing in a dark condition. Select On to turn on the AF assist beam, or Off to disable the function.





When the AF-assist beam is turned on, hold the shutter button halfway, and the camera will project the AF beam at the subject for focus assistance.

Expo metering

Use this setting to select an area for the exposure to be obtained.



There are three options:

• Spot: Spot metering

• Center: Center-weighted average metering

• Ai AE: Artificial intelligence automatic exposure Ai AE

Continuous shot

Use this setting to perform continuous shooting. When this function is active, keep holding down the shutter button for continuous shooting.



There are four options:


- Unlimited
- 3 Shots: Capture up to 3 consecutive pictures.
- 3 Shots (Last): Capture pictures continuously until the shutter button is released but only the last 3 shots are recorded.
- **Time-Lapse:** Time-Lapse automatically captures pictures in predefined intervals.



There are four options:

• 10 Sec. • 30 Sec.

• 1 Min. • 5 Min.



Refer to page 34 for details on **Continuous Shot** mode.

Quick review

This setting allows you to have a quick review of the image after taking a picture. You can change the length of time the image stays on the screen to a preset option.



There are four options:

- Off
- 1 Sec.
- 2 Sec.
- 3 Sec.

Digital zoom

This setting allows you to turn on/off the digital zoom function. When the digital zoom is turned off, only the optical zoom is available.



When the function is active, the focus bar on the screen will show the following colors.

- On: Blue
- Off: Grey

Print date

Add the date and time label to the image when shooting.



- Off
- Print Date
- Print Date/Time

B shutter (slow shutter)

When the Slow Shutter is active, the shutter will stay open for the pre-set exposure time when you keep the shutter button depressed.

(The Slow Shutter is only available under the **Manual** mode (Manual).



To set the exposure time: Touch the button to adjust the exposure time. Press and hold the button for 2 seconds to automatically increases / decreases the exposure time to the limit between 2 to 30 seconds.



The B Shutter (Slow Shutter) will be turned off when the value is set to zero. You need to reset the value for every shot. The default value of the camera is 0 seconds.



The use of tripod is recommended on a long-term exposure.

Blink detection

When Blink Detection is active, a warning message appears on the screen when the camera detects that a person's eyes are closed.



- On: Blue.
- · Off: Grey.



When the Blink Detection is active, the icon will be shown on the screen.

Movie recording setup

Mode icon: 🖀

When the movie recording is active, touch the movie recording button on the screen to enter the **Video recording** setup.

The Expo Metering Setup:

1. Touch the desired expo metering option directly.



There are three options:

- Spot: (Spot metering)
- Center: (Center-weighted average metering)
- Ai AE: (Artificial intelligence automatic exposure Ai AE)
- 2. Press the OK button to confirm (or press the return key to cancel and return to the playback main menu).

Playback Setup Menu

Mode icon: 🎢

In playback mode, touch the tool button to reach the playback setup menu.



In Playback Mode, there are four options:

- Protect
- Delete
- DPOF Settings
- Slideshow

Protect

This setting allows you to protect and lock one or more pictures or movies from being erased.




Protect single picture or movie:

- 1. In Playback mode, press the mode, button.
- Select Protect. When the sub-menu appears, select One.
- Use the left/right arrow key to view and choose the desired picture or video that you want to protect.
 Press the button, and press the button to confirm.

4. You may repeat the steps above to protect other picture(s) or video(s), or you may press the **return** key to go back to the previous page.

Protect all images:

- 1. In Playback mode, press the my button.
- 2. Select Protect. When the sub-menu appears, select AII.
- 3. Choose **OK** to protect all images, or press Cancel to return to the previous menu.
- 4. Select 'Reset' to cancel all protection.



A key icon will appear on the left of the screen to indicate that the picture/video is protected.

Delete

The camera provides three deleting options.



Files that are deleted cannot be recovered.



Delete One:

- 1. In Playback mode, press the my button.
- 2. Select Delete when the sub-menu appears, select Single.
- 3. Use the left/right arrow key to view and choose the desired file. Press the 📑 or 🧦 button, and press the OK button to confirm.

- 4. Repeat these steps to delete other files, or press the return key to go back to the previous page.
- When the picture includes a sound recording, you may choose to delete both together or the sound recording only.
 - 📑 Delete the picture and the recording sound together
 - Delete the recording sound

Delete All:

- 1. In Playback mode, press the TY button.
- 2. Select Delete when the sub-menu appears, select All.
- Press OK in the sub-menu, then, press the OK button to delete all files (or press Cancel to go back to the previous menu).
- 4. The protected file will not be deleted, unless the protection is cancelled.



When the icon oppears, the file has been protected. Please cancel the protection before deleting the file.



Once the file has been deleted, all configured DPOF values must be reset. (see page 60)

DPOF (Digital Print Order Format)

The DPOF allows you to choose a selection of images to be saved on your memory card so that a picture printing shop can print the selection without your having to tell them which images to print.



- One: Manually select each image to be printed with or without the date.
- All: Add all images on your memory card for printing with or without date.

Slide show

This setting allows you to view all pictures as a slideshow in the camera.

1. In playback mode, touch the tool button in the upper right corner and then press Slideshow to enter the set up menu.



- Play Effect: Off, Type 1, Type 2
- Play Interval: 1 sec., 3 sec., 5 sec.
- Repeat: On/Off
- 2. After choosing your settings, touch the button to play the slideshow.

Camera setting menu



The **camera setting** menu can be opened in all modes. Simply touch the **main** button to show the Setting menu. Touch the **camera setting** button to enter the camera setting menu.



- Touch the up/down arrows to scroll through the menu pages.
- Touch the setting you want to set up to enter the submenu.

Format memory



The Format Memory function will erase all data on the memory card and internal camera memory, including protected files.

- 1. Press Format memory in the camera setting menu.
- Press Yes and OK button to confirm (or press the return key to cancel and go back to the camera setting menu).



3. The current media device is formatted.

Beep

This setting allows you to adjust the volume of beep when buttons are pressed and change the tones for shutter, buttons, self-timer, and power-on/-off.

- 1. In the **camera setting** menu, select the **Beep** setting.
- 2. Touch the button to enter the sub-menu of the setting you want to set up.



3. In the sub-menu, press the desired selection and then press of button to confirm (or press the return key to cancel and go back to the camera setting menu).

LCD brightness

Use this setting to adjust the brightness of your LCD screen.

- In the camera setting menu, select LCD Brightness.
- 2. Touch the Auto or Manual button and then press of button to confirm.



- 3. By selecting the Manual option, you can adjust the brightness manually as desired by pressing the 💠 😑 button.
- Press and hold the 🖒 💳 button (for 2 seconds) to automatically adjust the level itself until it reaches the brightest or the darkest.

Power saver

This setting allows you to save power and get the maximum possible running time for your battery. Follow the steps below to turn off the LCD screen and camera automatically after a period of idleness.

- 1. Select **Power saver** in the **camera setting** menu.
- 2. Press the 🕒 💳 button to adjust the idle period before the **LCD screen** or **the camera** is automatically power-off.



- LCD Screen: Power On/30 sec./1 min./2 min.
- Camera: Power On/3 min./5 min./10 min.

Date / Time

Use this setting to change the date and time

- 1. In the camera setting menu, select Date/Time.
- Touch the date or time segment to be adjusted, then touch the up/down arrows to change the values.



3. Press the OK button to confirm the date and time setting.

Zone

The World Time setting is a useful function on your overseas trips. This feature enables you to display the local time on the LCD screen while you are overseas.

 In the camera setting menu, select Time zone to enter the World Time menu.



- 2. Press the buttons to set up the **local time zone** (1) or **overseas time zone** (2).
- 3. Use the **left/right** arrow key to select a city located in the same time zone. Press the button to confirm.

File number

After capturing pictures or movies, the camera will automatically save the file with a numeric suffix. This setting allows you to decide whether the numbers should continue from the last photo taken or reset the counter to 1 and save the files in a new folder on the memory card.

- In the camera setting menu, select File numbering to enter the setting.
- Select Reset or Continue. Press the button to confirm.



Language

This setting allows you to set the language of the camera.

- 1. In the camera setting menu, select Language.
- 2. Press the **up/down** arrow key to choose your language.



3. Press the language button and then **OK** button to confirm.

Video system

Use this setting to determine your video system in the current area.

- In the Camera Setting menu, Select the Video system.
- Select NTSC or PAL, and press the button to confirm.



The camera supports two different video output signals – **NTSC** or **PAL**, depending on the region.

NTSC: USA, Canada, Taiwan, Japan, etc.

PAL: Europe, Asia (excluding Taiwan), Oceania, etc.




The TV output will not display properly if an incorrect video system is selected.

Copy to card

Use this setting to copy the files stored in the internal memory to the memory card.

- 1. In the camera setting menu, select Yes.
- 2. Select **Yes** or **No**, and press the on button to complete.



Reset settings

Use this option to restore the camera to the factory default settings.

- 1. In the camera setting menu, select Reset.
- 2. Select **Yes** or **No**. Press the OK button to confirm.



FW version

Use this setting to view or update the current firmware version of the camera.

1. In the Camera Setting menu, select the **FW version**.



- 2. When no new firmware version is found in the SD card, the screen shows the current camera firmware version of the camera.
- When a new firmware version is found in the SD card, select Yes to continue the update (or No to cancel). Press the OK button to confirm.


Camera connection

Connecting to a TV

You can connect your camera to your television, computer, or printer to view the picture(s) or video(s) you have taken.

By using the AV Cable, you can view the captured picture(s) and video(s) on a TV. Follow the steps below to connect the supplied AV cable to a TV:

- Choose [NTSC] or [PAL] to match your TV video standard (see page 66) and then turn off the camera.
- Connect one end of the AV Cable to the USB/AV OUT port on your camera.
- Connect the plugs on the other end of the cable to the audio and video input ports on the TV.
- 4. Turn on the camera and the TV.





Make sure that both the camera and TV are turned off before connecting the AV cable.



Use a fully charged battery to prevent the camera from turning off unexpectedly while connected.

Connect Your Camera to a HDMI TV to View Videos


HDMI (High Definition Multimedia Interface), is a fully digital audio/video transmission interface, through which uncompressed audio and video signals are transmitted.

Direct transmission of digital video signals to your TV reduces conversion loss and improves image viewing quality.



Note that your camera and TV should be turned off before connecting them.

- 1. Select [NTSC] or [PAL] based on the TV video format (see page 66) and turn off your camera.
- Use a high-definition output terminal cable (optional) to connect your camera to an HDMI ready TV.



3. Turn on the camera and TV and then select the appropriate screen values from the output formats of your camera. The viewing experience may vary depending on the output values you choose.





Select resolution

Select screen color format

4. Once an output format is selected, the LCD screen on the camera will go blank (although it is still on) and your TV will then display the images and menus.



When the resolution is set to 1920 x 1080i, you can playback pictures only, and video playback is not possible. The maximum TV resolution for video playback is 1280 x 720P.



Refer to your TV instruction manual for information on what resolution sizes it will support. The resolution and output formats that are not supported will be grayed out on the camera's LCD screen.

Connecting to the PC

Use the USB Cable and ArcSoft software (CD-ROM) supplied with your camera to copy (transfer) pictures to a computer.

Setting the USB mode

Since the camera's USB port can be set to connect with either a PC or a Printer, the following steps will allow you to ensure that the camera is correctly configured to connect with a PC.

- In the camera setting menu, select USB Connection.
- Select the desired connection. Press the button to confirm.




Transferring files to your PC

The computer will automatically detect the camera as a removable drive. Double-click **My Computer** icon on the desktop to locate the removable drive and to copy the folders and files in the drive to a directory on your PC as you would copy any typical folder or file.

By using the USB Cable, you can transfer the captured picture(s) and video(s) to a PC. Follow the steps below to connect the camera to a PC.

- Start up a computer to which the ArcSoft software has been installed.
- 2. Make sure both the camera and PC are turned on.
- Connect one end of the supplied USB cable to the USB/AV OUT port on your camera.
- 4. Connect the other end of the cable to an available USB port on your PC.



5. Disconnect the cable after the transfer is complete.

If the USB option is set to [PC]:

Turn off the camera and disconnect the USB Cable.

If the USB option is set to [PC (PTP)]:

Remove the camera from the system as described below before turning off the camera and disconnecting the USB cable.

Window XP Home Edition/XP Professional

Click the [Safely Remove Hardware] icon () in the taskbar and select [Safely remove USB Mass Storage Device] from the menu displayed.



Windows 2000 Professional

Click the [Unplug or Eject Hardware] icon () in the taskbar and select [Stop USB Mass Storage Device] from the menu displayed.



Macintosh

Drag the untitled icon to the Trash. ("Untitled")



Connecting to a PictBridge compatible printer



PictBridge allows printing images from a memory card in a digital camera directly to a printer, regardless of brand.

To find out if a printer is PictBridge

compatible, simply look for the PictBridge logo on the packaging or check the manual for specifications. With the PictBridge function on your camera, you can print the captured pictures directly with a PictBridge compatible printer using the supplied USB Cable, without the need for a PC

Setting the USB mode

Since the camera's USB port can be set to connect with either a PC or a Printer, the following steps will allow you to ensure that the camera is correctly configured to connect with a printer.

- 1. In the camera setting menu, select USB Connection.
- 2. Select **Printer**. Press the OK button to confirm.







When the camera restarts, the USB mode will automatically switch to the PC connection mode.


Connecting the camera and printer.

- 1. Make sure both the camera and printer are turned on.
- Connect one end of the supplied USB Cable to the USB port on your camera.
- 3. Connect the other end of the cable to the USB port on the printer.



If the camera is not connected to a PictBridge compatible printer, the following error message will appear on the LCD screen.





Using the PictBridge menu

After setting the USB mode to printer, the **DPS** menu will appear.



Select and press a setting button to enter the sub-menu.

Refer to the following sections for details of all the settings.

With/Without the picture date printed

When you have set the date and time in the camera, all pictures you have taken will be saved with the date and time. See the following steps to print out the pictures with date/time.

 In the DPS menu, select With date/time printed or Without date/time printed. The screen below will be shown:



2. Touch the **left/right** arrow to browse the pictures.

- 3. Use the \Leftrightarrow \Longrightarrow button to select the print quantity of the selected image.
- 4. Press the OK button to confirm when all images have been set. The screen below will be shown when confirmed:



5. When the printing is complete, the camera will show the **DPS** menu automatically.

Print all index

This function allows you to print all images in the camera in a thumbnail index.

In the DPS menu, select Print all index items.
 The screen will show as below.




2. Select **Yes** to continue (or **No** to cancel).

Print the DPOF image

To print **DPOF** images, you need to select the images for the DPOF setting in advance. Refer to **DPOF** section on page 60.

 In the **DPS** menu, select **DPOF** Images to print. The following screen will be shown:



2. Select Yes to continue (or No to cancel).

Disconnect the USB cable

Select the **USB Disconnecting** icon at the upper right corner of the screen to exit the **DPS** menu. The screen shows the 'Disconnect the USB cable' message.



Once this message is shown on screen it is safe to disconnect the USB cable from the camera and the printer.

Appendices

Specifications: E1050TW



"Design and specifications are subject to change without notice."

Effective Image Sensor Pixels		10.1 Megapixels	
Image Sensor		10.7 Megapixels [1/2.33" Charge Coupled Device (CCD)]	
	Focal Length F =	5.1mm (Wide) ~ 25.5mm (Tele)	
	[35mm film equivalent]	[28mm (Wide) ~ 140mm (Tele)]	
	F number	F3.3 (Wide) ~ F5.1 (Tele)	
Lens	Lens Construction	9 elements in 8 groups	
	Optical Zoom	5X	
	Focusing Range	Normal: 60cm ~∞ ; (Tele) 80cm ~ ∞ Macro: (Wide) 5cm ~ 60cm	
Anti-Handshal	xe .	Electronic Image Stabilization	
Digital Zoom		4.5X digital zoom (Combined Zoom: 22.5X)	
Number of	Still Image	10MP, 9MP (3:2), 8MP, 7MP(16:9), 5MP, 3MP, 0.3MP	
Recording Pixels	Movie	1280x720pixels: 25fps/15fps, 640x480pixels: 30fps/15fps, 320x240pixels: 30fps/15fps	

Image Compression		Best, Fine, Normal	
DCF, DPOF (Ver1.1) Support		Yes	
	Still Image	Exif 2.2 (JPEG)	
File Format	Movie	Image Compression: MPEG4, Audio: G.711 [Monaural]	
	Audio	WAVE [Monaural] (Max 60 seconds)	
Shooting Modes		Auto, Manual, Image Stabilization, Movie, Panorama, Scene (Sport, Children, Indoor, Leaf, Snow, Sunset, Fireworks, Glass, Museum, Landscape, Night Landscape, Night Portrait, Portrait)	
Smile Detection	on	Yes	
Blink Detection		Yes	
Face-Detection		Yes	
Red-eye Removal		Yes	
Panorama Stitching		Yes	
LCD Display		3.0 inch (230,400 pixels) TFT-LCD (Touch Pannal)	
ISO Sensitivity		Auto, ISO 80/100/200/400/800/1600	

AF Method	Single AF, Multi-AF (TTL 9-point), Face-Detection, AF Assist Light (On/Off)	
Light Metering Method	Artificial Intelligence AE (Ai AE), Center-weighted Average, Spot (Fixed to center of frame)	
Exposure Control Method	ProgramAE (AE-lock available)	
Exposure Compensation	±2 EV in 1/3 steps	
Shutter Speed	4 ~ 1/2000 second (Manual 30s)	
Continuous Shooting	Approx. 1.8 fps (Large/Fine Mode)	
Playback Modes	Single Photo, Index (4/9 thumbnails), Slide Show, Movie (Slow-Motion possible), Zoom (Approx. 2X~8X), Audio, Histogram Display	
White Balance Control	Auto (AWB), Daylight, Cloudy, Fluorescent, Fluorescent CWF, Incandescent, Manual	
	Auto/Red-Eye Reduction/Forced Flash/No Flash/Slow	
	Synchro/Red-Eye Reduction+Slow Synchro	
Internal Flash (Shooting Range)	Gno. 5.3 (ISO 100)	
	(Shooting Range) Wide: Approx. 0.3m~3.2m / Tele: Approx. 0.3m~2.1m (ISO 400)	

Pacarding Modia	Internal Memory: 26MB	
Recording Media	SD Card/SDHC Card (Up to 4GB support)	
Other Features	PictBridge, ExifPrint Support, Multi-language Support (23 languages), HD Still Output	
Jacks	USB2.0/AV-OUT (Integrated Proprietary Connector), HD OUT	
Power	Rechargeable Lithium-ion Battery GB-40, 3.7V 1050mAh	
Battery Charger	Input Voltage : AC 100 to 240V, 50/60Hz, 100mA Output Voltage : DC 4.2V, 500mA"	
Shooting Capability (Battery Performance)	Approx. 200 shots (based on CIPA Standards)	
Operation Environment Temperature: 0~40 ⁰ C, Humidity: 0~90%		
Dimensions (W x H x D)	93mm x 58mm x 23.8 mm	
Mass	Approx. 145g (Body only)	

Error messages

Messages	Explanation	
No card	• The memory card is not inserted.	
Card error	The memory card is not formatted.	
Card full	The memory card is full and cannot store any new images.	
Write protect	The memory card is write-protected.	
Picture error	 The picture is not captured correctly. The picture is damaged.	
No picture	There are no images in the memory card or in the internal memory.	
Lens error	The lens is probably stuck and the camera will power off automatically.	
System error	Unexpected error encountered.	
No sound file	There are no audio files in the memory card or in the internal memory.	
Image cannot be saved	The write protection switch in the memory card is set to the "LOCK" position.	

Messages	Explanation
Card is not formatted, format?	Confirm whether the memory card should be formatted.
This image cannot be deleted	The picture or video you are trying to delete is protected.
Cannot record movie	 The write protection switch in the memory card is set to the "LOCK" position.
Sound file cannot be saved	 The write protection switch in the memory card is set to the "LOCK" position.
Warning! Camera recording, please wait.	No other actions allowed to perform during video/audio recording.
Warning!! Battery exhausted.	• The battery is out of charge.
This file cannot be played back	The picture format cannot be recognized by the camera.
No connection	The camera is not connected to the printer correctly.
Print error	There is a problem with camera or printer.
Cannot print	 Check that the printer is out of paper or out of ink. Check if the printer has a paper jam.

Troubleshooting

Problem	Possible causes	Solution
Camera does not turn on.	The battery has run out.The battery is not inserted correctly.	 Charge the battery or replace with a fully charged battery. Re-insert the battery observing the correct polarity.
Camera turns off suddenly during operation.	• The battery has run out.	 Charge the battery or replace with a fully charged battery.
The picture is blurred.	The lens is dirty. Graph appears when taking pictures.	 Use a soft cloth to clean the lens on your camera Use the Image Stabilization mode.
Images, video clips, and audio files cannot be saved.	• The memory card is full.	 Replace the memory card with a new one. Delete unwanted images. Unlock the memory card.

Problem	Possible causes	Solution
No picture is taken when pressing the shutter button.	 The memory card is full. No available space to store the files. The mode dial is in Playback mode. 	 Replace the memory card with a new one or clean off current memory card. Delete unwanted images. The memory card is locked. Turn the mode dial to any still shooting mode.
Images cannot print from the connected printer.	 The camera is not connected to the printer correctly. The printer is not PictBridge compatible. The printer is out of paper or out of ink. The paper is jammed. 	 Check the connection between the camera and printer. Use a PictBridge compatible printer. Load some paper in the printer. Replace the ink cartridge in the printer. Remove the jammed paper.

http://www.ge.com/digitalcameras

